

•

Wunsch	ESU name	Untername	Aktion	Unteraktion	Feld	IST	SOLL
							ändern in
Tagfahrlich hinten ein	EMM	USM_CMF_xxx	Lichter	Lichter Configuration	E_B_DRL_withTail	0	1
WelcomeSequenz	Audio[\$13]	RadNav v2.3	Configuration	ECU Configuration II	welcome sequenz	Initiale	RS...GT...
Außentemp.im Tacho	Tableau de bord [\$51]	Cluster_15-40_v3.30.02	Ecrans Configuration	Conf Prestation	External_Temperature_CF		External Temp. Measurement and Display
PDC im Tacho	Tableau de bord [\$51]	Cluster_15-40_v3.30.02	Ecrans Configuration	Conf Prestation IHM	UPAMMI_CF	without	with front and rear UPA MMI
Tacho max.260 km/h	Tableau de bord [\$51]	Cluster_15-40_v3.00	Ecrans Configuration	Conf Prestation VEH	SpeedSCaleType_CF	240 km/h	260 km/h
Nachwischer	UCBIC/BFR[\$26]	C1A BCM DDT_9	FrontWIPER	FrontWiper-Config	FRONT_DROP_WIPE_CF	true	false
Komfort-Blinker	UCBIC/BFR[\$26]	C1A BCM DDT_9	Flashers	Flasher-config	T_PULSE_CF	true	false
Blinken bei bremsen/Unfall	UCBIC/BFR[\$26]	C1A BCM DDT_9	Flashers	Flasher-config	HZARD_WITH.....	true	false
ETA (nur Espace) Fußwedelsensor	UCBIC/BFR[\$26]	C1A BCM DDT_9	LinII	LinII-Configuration	EASY_TRUNK_ACCESS_ECU_CF	false	true
Gangwechselanzeige Automatic	Tableau de bord [\$51]	Cluster_15-40_v3.30.02	Ecrans Configuration	Conf Prestation VEH	GearBoxType_CF	xxx	entsprechend auswählen
Start&Stop eliminieren	EMM	USM_CMF1_Sailing_B4	BatteryGauge	BatteryGauge Configuration	E_B_STOPSTARTInhibit	No Value	1
Anschallgurt Warnung eliminieren	Tableau de bord [\$51]	Cluster_15-40_v3.30.02	Ecrans Configuration	Conf Prestation VEH	Front SBR	not inhibited	inhibited
Müdigkeitserkennung	Audio[\$13]	RadNav v2.3	Configuration	RadNav Configuration 1.1	Unstable trajectory alert	absent	present
Tagfahrlicht aus bei Blinken	EMM	USM_CMF_xxx	Lichter	Lichter Configuration	E_B_DRLinhibitByFlasher	0	1
Dach öffnen unter 0° C	UCBIC/BFR[\$26]	C1A BCM DDT_9	Defroster	Defroster-Configuration	OPENABLE_ROOF_CF	false	true
Spurwarner(LDW) km/h Bereich	FCAM	FrontCamera2014_ECU_3.0	Diagnostic	4_Camera_Configuration	LDW MIN SPEED ACTIV 2x		km/h eintragen
Pedal(Kupplung od.Bremse)beim Starten erforderlich	UCBIC/BFR[\$26]	C1A BCM DDT_9	FAL	FAL-Configuration	START_WITH_PEDAL_PRESS_CF	false	true
Frontblinker mit Birne ?	UCBIC/BFR[\$26]	C1A BCM DDT_9	HWDiagnosticManagement	HWDiagnosticManagement-Configuration	FRONTflashers_withBULB	false	or true

auch Frontblinker mit Birne ?	UCBIC/BFR[\$26]	C1A_BCM_DDT_9	HWDiagnostic	HWDiagnostic-Configuration	FRONTflashers_withBULB	false	or true
Toter Winkel warner	Aide au parking	USA Bosch GEN5_V7.7	BSW	speed conditions	Geschwindigkeiten anpassen		